



# MOUNT WITH SEALING TAPES

## PRE-INSTALLATION



IDIGO Pipe Marker



Cloth



Isopropyl Alcohol (IPA)









Squeegee



Garbage Bags

## INSTALLATION

<p><b>1</b> Determine location of marker (refer to project specific compliance rules).</p> 	<p><b>2</b> Align the marker according to the P&amp;ID/ GA drawings.</p> 	<p><b>3</b> Carefully peel-off the release liner on the top of the sticker. Ensure marker stays in position.</p> 
<p><b>4</b> Paste the marker down, ensuring that it is still aligned with the pipe.</p> 	<p><b>5</b> Press the marker down further from the center using the squeegee. Always begin from the center and rub out and away towards the edges.</p> 	<p><b>6</b> Rotate the marker to ensure that it is (1) in the correct orientation and (2) viewable from human access areas.</p> 

## GENERAL

- To clean, wash with a degreaser, rinse, and dry with a clean cloth. Wipe down entire expected area in one direction with isopropyl alcohol using a clean, lint-free cloth to avoid recontamination. Let the alcohol evaporate before installation.
- Keep ready-to-install pipe markers dry and away from any liquids to avoid damage.
- Surface should feel slightly cold to warm on touch. Temperature should range from 10°C (50°F) to 40°C (95°F) during application.
- Please collect all liners and dispose accordingly.